
Installation Instructions:

Sure Stride® Impressions

High Traffic, Indoor Applications

No Art Fees
No Set-Up Fees
5 Day Production



1. The floor must be clean and dry.
2. Position the mat in the desired location, then press and smooth the mat into place.