

---

## Installation Instructions:

# Sure Stride® Directional Mats

No Art Fees  
No Set-Up Fees  
5 Day Production



High Traffic, Indoor Applications

1. The floor must be clean and dry.
2. Position the mat in the desired location, then press and smooth the mat into place.