

## Cleaning Instructions:

### Stick-and-Stand™ Mats

High Traffic, Indoor Applications

No Art Fees  
No Set-Up Fees  
5 Day Production



## Routine Maintenance

- Do not pick up the mat to clean the floor underneath until you are ready to replace it.
- Floor scrubbers, vacuums, brooms, and mops will pass right over it without causing damage to the mat.
- Use low settings for water and pressure, but note that extended use of floor scrubbers could result in removal of the printed design.
- Designed to dissipate water and dry quickly, however, standard fans and floor blowers can be used to expedite drying. For extremely wet conditions, use a wet vacuum or extractor to remove excess water.
- Designed to last up to 3-4 months under normal conditions. If the mats are installed in a high-traffic area or shows signs of wear or a weakened bond to the floor prior to its intended life, it should be replaced.