

## Stick & Stand / Sure Stride Directional Mats Cleaning Instructions

### Installation Instructions

- Clean & dry floor
- Position the mat in the desired location, then press and smooth into place

### Replacement Frequency

- Designed to perform up to 3 to 4 months under normal use
- Do not pick up mat to clean the floor underneath until you are ready to replace it

### Cleaning

The mats feature a low profile and can be left in place during daily floor cleaning activities. Floor scrubbers, vacuums, brooms, and mops will pass right over it without causing damage to the mat. Standard floor scrubbers may be used to clean the mat. Use low settings for water and pressure, but note that extended use of floor scrubbers could result in removal of the printed design.

The mats are designed to dissipate water and dry quickly, however, standard fans and floor blowers can be used to expedite drying. For extremely wet conditions, use a wet vacuum or extractor to remove excess water.